Task:	0 – Not	1 – Partially	2 – Fully	Notes
	Proficient	Proficient	Proficient	
Tool Placement Exercise 3				
Assemble hood stand properly.				
Clean/polish hood.				
Attach dent light in proper				
location.				
Choose appropriate dent rod for				Select tool based on
each pea-sized circle.				distance.
Walk tool tip across circle with S-				Leverage point should be
hook.				no more than half-way
				point of tool.
Use appropriate tool pressure to				
create a high spot.				
Check and reposition Dent Light.				Light too close will wash
				out the exercise.
Scan the reflection.				